

[Home](#) ■ [HUBER Report](#) ■ [Fine screening – the cost-effective alternative to primary settlement tanks](#)

## Fine screening – the cost-effective alternative to primary settlement tanks

Small space requirements and low investment costs are arguments in favour of fine screening

*In the discussion about limited resources and energy saving in sewage treatment plants alternative sewage treatment methods are increasingly becoming a focal point. Fine screening represents an interesting alternative to primary settlement tanks as it can achieve similar reduction rates on a much smaller footprint and with significantly lower investment costs.*



RoMem liquid fine screen with apertures up to as small as 0.2 mm

The task of primary settlement tanks is to mechanically remove very fine particles that settle on the bottom or float to the surface. The solids that settle on the tank bottom are primarily organics. After removal from the tank bottom this material, also called primary sludge, accumulates in the pump sump from where it is usually delivered to the digester. The two disadvantages of primary settlement tanks are high space requirements and high investment costs.

Fine screening with up to 0.2 mm apertures can achieve the same removal rates on a much smaller footprint and with significantly lower investment costs. For this application, we have chosen the ROTAMAT® Membrane Screen RoMem liquid, a screen that has been designed on the basis of our proven [ROTAMAT® screening systems](#). Due to its drum-shaped screen basket and installation angle the RoMem liquid screen provides a large screening surface. The flow resistance and headloss of the screen are therefore low even with higher flow rates.

In contrast to common screen designs (slots or perforations), our RoMem liquid screen is equipped with square mesh which can retain even very small particles due to its two-dimensional structure. Even the finest slot screens are by far not able to achieve the same retention. In addition, square meshes have a relatively large free surface and are therefore able to cope with high hydraulic capacities and nevertheless achieve excellent separation results.



*Wash Press WAP liquid*



*dewatered screenings*

Another advantage and special feature of the RoMem liquid screen is that the screenings are discharged either by gravity or by pump and delivered to further treatment facilities. Like with primary settlement tanks the separated solids can be used as a co-substrate for sludge digestion. Optionally, they can be further dewatered in a wash press and discharged into a container. If the screenings are passed on to the sludge treatment system, the fibrous material contained can be introduced as additional bulking material. Compared to sludge treatment without introducing fine screenings, increased solids contents can be achieved with reduced coagulant agent volumes.

As mentioned above, the screenings can be further dewatered in a WAP Wash Press and discharged into a container instead of introducing them into the sludge treatment system. The WAP Wash Press achieves dewatering results of about 35% dry residue. The removal of solids and their disposal as screenings reduces the hydraulic load on the sludge treatment system.

As fine screening can achieve the same removal rates on a smaller footprint and with lower investment costs, it is a highly interesting alternative to primary settlement tanks. Fine screening should especially be considered as an economical and efficient option for upgrading smaller sewage treatment plants without preliminary treatment. Due to the high removal rates that can be achieved with fine screening the load on downstream biological treatment systems can be reduced and their clarification capacity increased accordingly. The screenings can be used for sludge digestion to increase gas production. Alternatively, they can be dewatered in a wash press before disposal.

**Related Products:**

- [Ultra Fine Screens](#)
- [Microscreens](#)

**Related Solutions:**

- [HUBER Solutions for Removal of very fine Solids by Micro-Screening and Filtration](#)



**Hydroflux Pty Ltd**  
Level 26, 44 Market St  
Sydney NSW 2000  
Australia

Phone +61 2 9089 8833  
Fax +61 2 9089 8830  
Email [info@hydroflux.com.au](mailto:info@hydroflux.com.au)  
WWW [www.huber-technology.net.au](http://www.huber-technology.net.au)

Representative of the HUBER group:  
[www.huber.de](http://www.huber.de)

---